

# **Air Quality Management Guideline**

9TP-SD-107/2.0

Supporting Document – Applicable to Transport Projects Delivery Office

# **Quality Management System**

Status:	Approved	
Version:	2.0	
Branch:	Planning and Environment Services	
Business unit:	Environmental Management	
Date of issue:	14 April 2015	
Review date:	14 April 2016	
Audience:	Project Delivery/External TSR	
Asset classes:	<ul><li>☑ Heavy Rail;</li><li>☑ Light Rail;</li><li>☑ Multi Sites;</li><li>☑ Systems;</li><li>☑ Fleets</li></ul>	
Project delivery model:	TP Project/Alliance/Novo Rail	
Project type:	Not Applicable	
Project lifecycle:	ct lifecycle:  ☐ Feasibility; ☐ Scoping; ☐ Definition; ☐ Construction readiness; ☐ Implementation; ☐ Finalisation; ☐ Not applicable	
Process owner:	Technical Director Planning and Environment Services	



# Project type: Not Applicable

# **Document history**

Version	Date of approval	Doc. control no.	Summary of change
1.0	30 July 2014	3145234_5	First issue
2.0	14 April 2015	3145234	Updated to be published to TfNSW website

# **Table of contents**

1.	Purpose	3		
	Scope			
	Definitions			
	Accountabilities			
	. Legislative requirements			
	Air quality management			
	6.1. Planning and pre-construction			
	6.2. During construction			
7.	Monitoring			
	7.1. Visual observations			
	7.2. Weather and wind monitoring	6		
	7.3. Dust monitoring			
8.	Related documents and references			

Project type: Not Applicable

### 1. Purpose

The purpose of this document is to provide guidance with regard to managing air quality and emissions on Transport Projects Delivery Office (TPO) project sites. The inappropriate management of emissions has the potential to result in health impacts, loss of amenity and community dissatisfaction and environmental degradation. Such impacts are primarily associated with dust from construction activities and exhaust emissions from vehicles, plant and equipment.

In New South Wales there are strict laws to prevent air pollution. In addition, planning approvals for projects and other authorisations (such as Environment Protection Licences) may contain specific requirements relating to air emissions. Appropriate air quality management measures need to be implemented to minimise air pollution, and minimise the risk of penalties to individuals, TPO and its contractors.

### 2. Scope

This guideline applies to management and mitigation of dust generation and emissions from vehicles, plant and equipment on TPO project sites. It does not apply to emissions from chemicals (refer to Chemical Storage and Spill Response Guidelines – 9TP-SD-066).

This guideline includes references to relevant legislative and regulatory requirements but is not intended to replace them. It is not intended to replace any requirements for air quality management identified as part of the environmental impact assessment process.

### 3. Definitions

All terminology in this document is taken to mean the generally accepted or dictionary definition with the exception of the following terms which have a specifically defined meaning:

**DDG** Dust deposition gauge

EPA Environmental impact assessment

NSW Environment Protection Agency

NSW New South Wales

**OEH** NSW Office of Environment and Heritage

POEO Act Protection of the Environment Operations Act 1997

**TfNSW** Transport for NSW

TPO Transport Projects Delivery Office (TfNSW)

TSR TfNSW Standard Requirement

### 4. Accountabilities

The Technical Director Planning and Environment Services is accountable for this Supporting Document. Accountability includes authorising the document, monitoring its effectiveness and performing a formal document review.

Project directors are accountable for ensuring the requirements of this document are implemented within their area of responsibility.



Project type: Not Applicable

Project directors who are accountable for specific projects/programs are accountable for ensuring associated contractors follow this document to the extent they are required under TSR E – Environmental Management and the contract.

Contractors are accountable for following this document, where this guideline forms a part of their contract.

# 5. Legislative requirements

Table 1 lists the relevant legislation/regulations for the management of air quality in NSW. Significant penalties can result in breaches of the listed legislation as a result of air pollution incidents.

To avoid breaches of legislation, it is important that TPO and its contractors are aware of their legislative requirements and that appropriate management measures are in place to minimise dust emissions and air quality impacts during construction.

Table1: Legislation and guidelines for management of air quality

Relevant requirement	Objectives and offences
POEO Act	Under the POEO Act it is an offence to:
Part 5.4 Air Pollution	(i) operate any plant in such a manner as to cause air pollution, if the air pollution so caused, or any part of the air pollution so caused, is caused by the occupier's failure:
	(a) to maintain the plant in an efficient condition, or
	(b) to operate the plant in a proper and efficient manner.
	(ii) undertake maintenance work on any plant in such a manner as to cause air pollution, if the air pollution so caused, or any part of the air pollution so caused, is caused by the occupier's failure to carry out that work in a proper and efficient manner.
	(iii) deal with materials in such a manner as to cause air pollution, if the air pollution so caused, or any part of the air pollution so caused, is caused by the occupier's failure to deal with those materials in a proper and efficient manner.
	air pollution means the emission into the air of any air impurity
	air impurity includes smoke, dust (including fly ash), cinders, solid particles of any kind, gases, fumes, mists, odours and radioactive substances
	deal with materials means process, handle, move, store or dispose of the materials
	materials includes raw materials, materials in the process of manufacture, manufactured materials, by-products or waste materials
	Air pollution is a Tier 2 offence attracting penalties up to \$1 million for a corporation and \$250,000 for individuals.
Protection of Environment Operation (Clean Air) Regulation 2010	Schedule 6 of the regulation (Standards of concentration of non- scheduled premises) applies to construction activity in NSW and sets out concentration limits for solid particulates and smoke emissions.
Approved Methods for the Modelling and Assessment of Air Pollutants in NSW 2005	Lists the statutory methods for modelling and assessing emissions of air pollutants from stationary sources in NSW. Section 7.1 outlines the impact assessment criteria for common pollutants.

Planning and Environment Services: Environmental Management

Project type: Not Applicable

Relevant requirement	Objectives and offences
Approved Methods for the Sampling and Analysis of Air Pollutants in NSW 2007	Lists the statutory methods that are to be used to model and assess emissions of air pollutants from stationary sources in NSW.

# 6. Air quality management

Construction activities that typically result in the generation of dust include:

- site preparation including clearing of vegetation, removal of topsoil and demolition
- earth works, particularly rock hammering, cutting, profiling and breaking, crushing and grinding, movement and stockpiling of materials
- surface grading and compaction
- vehicle and plant movement on unsealed haul roads.

Disturbed and exposed areas including haul roads, embankments and cuttings and stockpiles also have the potential to generate dust during windy conditions.

Excessive emissions from vehicles, plant and equipment typically result from poor maintenance and are more likely to occur when the engine is under load.

### 6.1. Planning and pre-construction

Prior to the commencement of construction the following management measures should be considered when planning the works:

- Incorporate specific management measures identified in the EIA into the Construction Environmental Management Plan and environmental control maps (refer to the <u>Guide to Environmental Control Map – 3TP-SD-015</u>).
- Incorporate specific management measures identified in the EIA into the site induction, toolbox talk and pre-start meetings.
- Minimise and stage land clearing to retain existing vegetation where possible (refer to the <u>Vegetation Management (Protection and Removal) Guideline – 9TP-SD-111</u>).
- Where possible schedule construction activities that may generate dust to avoid periods with unfavourable wind conditions.
- Plan deliveries to site and plant movements on site to minimise idling times and avoid vehicles idling in close proximity to adjacent residents and businesses.
- Develop a monitoring regime and protocols to respond quickly to unfavourable weather conditions, including restricting activities, covering exposed surfaces / stockpiles and increasing watering.
- Ensure relevant construction plant has effective watering mechanisms to damp down during works, particularly for rock hammering, cutting, profiling and breaking, and crushing, grinding and sorting.



#### 6.2. **During construction**

During construction the following air quality management measures should be implemented:

- Regularly water all exposed surfaces, including haul roads, using water sprays or sprinkler systems.
- Minimise the number of stockpiles onsite, avoid stockpiling in exposed areas and ensure long term stockpiles are covered or stabilised.
- Progressively rehabilitate exposed areas on completion of different work stages, including providing temporary cover and commencing permanent landscaping as early as possible.
- Ensure vehicles and mobile plant use designated haulage and access routes and restrict traffic speeds.
- Provide temporary sealing of roads and other exposed areas on site such as spray sealing or applying a crusting or binding agent.
- Ensure that all vehicles transporting soils, rock or other materials are covered when entering or exiting the site.
- Wash and remove soil from vehicle and mobile plant undercarriage and wheels.
- Provide stabilised site access and clean roads and access points as required.
- Maintain all vehicles and plant in accordance with manufacturer specifications.

#### **Monitoring** 7.

#### Visual observations 7.1.

Visual observations of air quality should be undertaken daily on site in order to identify construction activities, vehicles, plant or equipment that are generating excessive air emissions. Additional mitigation strategies should be implemented where necessary.

Operation of vehicles, plant and equipment with excessive exhaust emissions (generally when visible continuously for more than 10 seconds) should cease until maintenance is undertaken and performance improved.

#### 7.2. Weather and wind monitoring

Daily monitoring of weather forecasts is also recommended to determine when adverse weather conditions are predicted. Provision of a weather station is also recommended, or a wind speed gauge as a minimum. Weather monitors can provide an alert when wind reaches a set velocity, indicating high risk conditions when activities may need to be restricted or additional mitigation implemented.

#### 7.3. **Dust monitoring**

Dust monitoring may be required and is typically undertaken using a DDG to assess deposited matter over a fixed period, usually 30 days. Alternatively, high volume air samplers may be used to provide data over 24 hour periods or in real time.

Monitoring must be undertaken in accordance with the applicable guidelines and industry standards, including the following:



- EPA Approved Methods for the Sampling and Analysis of Air Pollutants (January 2007)
- EPA Approved Methods for the Modelling and Assessment of Air Pollutants (August 2005)
- AS/NZS 3580.1.1:2007: Methods for sampling and analysis of ambient air Guide to sitting air monitoring equipment
- AS/NZS 3580.10.1:2003 (R2014): Methods for sampling and analysis of ambient air Determination of particulate matter — Deposited matter- Gravimetric method
- AS/NZS 3580.9.6:2003 (R2014): Methods for sampling and analysis of ambient air —
   Determination of suspended particulate matter PM10 high volume sampler with size-selective inlet Gravimetric method

# 8. Related documents and references

### Document title and number

Environmental Incident Classification and Reporting – 9TP-PR-105

Guide to Environmental Control Map – 3TP-SD-015

Vegetation Management Guidelines - 9TP-SD-111

Chemical Storage and Spill Response Guidelines - 9TP-SD-066

EPA Approved Methods for the Sampling and Analysis of Air Pollutants (January 2007)

EPA Approved Methods for the Modelling and Assessment of Air Pollutants (August 2005)

<u>Australian and New Zealand Standard AS/NZS 3580.1.1:2007: Methods for sampling and analysis of ambient air-</u> Guide to siting air monitoring equipment

AS/NZS 3580.10.1:2003 (R2014): Methods for sampling and analysis of ambient air – Determination of particulate matter – Deposited matter- Gravimetric method

AS/NZS 3580.9.6:2003 (R2014): Methods for sampling and analysis of ambient air Determination of suspended particulate matter – PM10 high volume sampler with size-selective inlet – Gravimetric method